

Please read these instructions carefully. Faulty parts which are under warranty should be returned.

INSTRUCTIONS TO FIT BATTERY LEADS**AKIT40**

1. Cut away the insulation from the positive and negative terminals using a sharp knife.
2. Undo the screws from each terminal and remove the old leads
3. Slide the new 'heat shrink' insulation on to the new battery leads and secure the leads to the battery. Please ensure that the red wire is attached to the red (positive) battery terminal.
4. Slide the insulation completely over the battery terminals and apply heat using a hairdryer or hot air paint stripper.

Hill Billy Ltd

PO Box 533 Sittingbourne Kent Me10 9BX England
Telephone 01795 413830 Fax 01795 413831



FILEADS.CDR